



KINGDOM ALL PURPOSE JOINT COMPOUND



DESCRIPTION

KINGDOM ALL PURPOSE JOINT COMPOUND READY-MIXED / NON-ASBESTOS JOINT COMPOUND special vinyl formulation that require minimal mixing to thinning provides a smooth seamless finish for Gypsum Board Wall, Ceiling Joints and brick wall. Kingdom All Purpose Joint Compound used for taping, finishing Gypsum Board Joints, filling, covering and for Final Touch-Up Coats in Interior Gypsum Board applications. It is an ideal material for embedding fasteners, corner surfaces where necessary. It can also be used to repair crack on brick wall surface.

FEATURES

- Durable
- Low Shrinkage
- Extra Fine Smooth Finishing Solutions
- Excellent Workability

PRODUCT SPECIFICATION

PAIL / BUCKET	28 kg
FOR JOINT FINISHING	28 kg, covers approx 182.56 ft (55.65m)
FOR TEXTURING	28 kg, covers approx 218.4 ft² (20.3m²)

Store at room temperature in a cool dry location. Keep away from direct exposure to sunlight. Protect freezing. The seal to be tightly secured.

PREPARATION

- Store Kingdom All Purpose Joint Compound at room temperature for 24 hours prior to the application.
- Stir content lightly, do not add water.
- Use directly from the container when use for covering embedded fasteners, corner beads and trims.
- If necessary add 1/2 pints (250ml) of water, remix gently.
- Do not add in any other material.
- Keep container covered when not in use

SANDING

Sanding is not allowed. If required, use very fine sandpaper of grit 160.

PRODUCT DATA SHEET

APPLICATION



1. Apply **Kingdom All Purpose Joint Compound** only on dry surfaces.



2. Apply thoroughly and allow each coat to dry before apply the next.



3. Keep air to the minimum, joint compound surface temperature 26/30°C within working area until joint are completely dry.

JOINT FINISHING

- Apply the thin layer of **Joint Compound** between the Gypsum Boards Joint with 6" wide blade knife, press Joint Tape firmly into the Joint Compound on the Joint and embed with 8" wide blade knife.
- Sufficient **Joint Compound** must be remain under the Joint Compound over the embedding coat and feather out beyond the first coat.
- Allow the second coat to dry thoroughly prior to the application of the finish coat.
- Apply the final finish thin smooth coat to the joints and fasteners and let dry (Use 10" wide blade knife for joints & 6" wide blade for fasteners)

FINISH INSIDE CORNERS

- Apply the **Joint Compound** on the both sides of inside corner with 6" wide blade knife.
- Fold the joint tape from center and press into the position.
- Embed the Joint Tape with knife.
- Excess **Joint Compound** to be removed.
- Then apply evenly a thin coat over the Joint tape on both sides and let dry.
- Apply second coat similarly slightly beyond the first coat and let dry.
- Apply the final finish thin smooth coat.

FINISH OUTSIDE CORNERS

- Fasten the Metal corner based or metal corner tape directly to drywall.
- Apply first coat on the both sides of external corner and let dry.
- Apply second coat slightly beyond the first coat and let dry.
- Apply the final finish thin smooth coat.

DECORATING

- Drywall surface must be clean, dry, free from dust and not glossy before any decorating.
- Decoration shall be such as painting or texturing.
- All directions by decorating shall strictly adhere according to the conditions as stipulated by decorating materials.